Safety instructions

DEVICE APPROVAL AND CONFORMITY WITH EC DIRECTIVES

Nubert electronic GmbH hereby declares that this product complies with the Directives 2014/53/EU and 2011/65/EU (RoHS), provided it is installed and used in accordance with the manufacturer's instructions. The full text of the EU Declaration of Conformity is available at the following internet address:
www.nubert.de/en/declaration-of-conformity

- Do not change the serial number on the speaker. It is part of the operating approval.
- If the loudspeaker is repaired or modified by workshops or other third parties not authorized by Nubert, it loses its operating license.
- Only accessories and devices may be connected which in turn comply with all legal requirements and are approved.
- The loudspeaker may only be used for the applications specified in the „Intended Use" section.

INTENDED USE

This speaker is designed exclusively for sound reproduction in dry rooms. Use the speaker only as described in this manual.
Any other use (particularly safety-relevant or medical use, installation in open environment like IP-certified products) is considered improper and may result in property damage or even personal injury. Nubert electronic GmbH does not assume any liability for damages caused by improper use.

SAFETY INSTRUCTIONS

The entire operating manual, in particular the safety instructions, must be read in full before connecting and commissioning the device. For your own safety, be sure to follow all warnings and safety instructions in this manual and on the speaker. The user is not permitted to carry out any work on the loudspeaker other than the described work. Keep this document so that you have access to it at all times. Furthermore, it must also be handed over to possible re-owners.

SYMBOL EXPLANATION

The following symbols may appear in the manuals or on the product:

The triangle symbol with an exclamation mark (without additional remark) indicates important information for commissioning, operation, and maintenance of the device.
The term **Caution!** next to the triangle symbol indicates a medium risk. Ignoring the warning may result in property damage.
The term **Danger!** next to the triangle symbol indicates a high risk. Ignoring the warning may result in injury or death.

This symbol indicates that you must read and follow the operating instructions and safety and warning notices before operating the device.

This symbol (triangle with lightning bolt) warns of hazardous voltages inside the housing and the risk of electric shock.

Devices with this symbol may only be used in dry environments indoors.

This symbol indicates that the device corresponds to electrical protection class 2 and therefore does not require grounding.

Devices and batteries marked with the crossed-out waste bin symbol must not be disposed of with household waste. Please also observe the following disposal instructions.

GENERAL INFORMATION

Never operate the loudspeaker unattended!

Danger of suffocation!
Never let children use or play with the speaker, remote control or packaging unattended. There is a risk that children will get caught in the packaging film and suffocate. Make sure that children cannot remove any small parts from the devices! These parts, like the remote control battery, could be swallowed and cause suffocation. In case of swallowing any parts, contact a doctor immediately!

Caution!
To avoid the risk of property damage, the loudspeaker must not be opened by the user. There are no user-serviceable parts inside the loudspeaker. Servicing and repairs must only be carried out by qualified personnel authorized by Nubert. In the event of service needs, please contact Nubert electronic GmbH directly (info@nubert.de)!

Caution!
Operating the loudspeaker despite damage may result in further defects. If any of the following conditions apply, the loudspeaker must be taken out of operation immediately. Please contact Nubert electronic GmbH without delay (info@nubert.de)!

- The loudspeaker has been damaged or has fallen.
- Objects or foreign bodies have entered the device.
- The loudspeaker smells burnt, emits smoke, or makes unusual noises.

Danger of injury or damage!
When moving the speaker, take care to avoid injury and damage!

Only use accessories recommended by Nubert!

INSTALLATION INSTRUCTIONS

Risk of injury or damage!
When moving the loudspeaker, do so with the necessary caution to avoid injuries and damage!

Caution!
An unstable location can damage the speaker.

- Only place the loudspeaker on a flat, stable surface and make sure that it cannot be knocked over!
- Also make sure that no unintentional pulling can occur on the cables to avoid knocking over the speaker or damaging the connection sockets!
- Keep strong mechanical shocks away from the loudspeaker!

Caution!
Excessive heat build-up inside the unit can shorten its service life or lead to fire.

- Never cover the back of the speaker! Make sure that there is a clearance of at least 10 cm and sufficient air circulation in the back area!
- Do not operate the speaker and remote control near heat sources such as radiators or stoves!
- Do not expose the speaker and remote control to direct sunlight.
- Never place burning candles or similar open fire sources on the
- loudspeaker!

Danger of explosion!
Installation in unsuitable locations can cause explosions.
Do not use the speaker or remote control

- in environments where there is a risk of fire or explosion!
- at extremely low or extremely high temperatures!
- near flammable gases or vapours!
- near strong dust!
- near flammable materials!

Danger of electric shock!
The loudspeaker carries mains voltage and voltages higher than 35 V AC or DC inside. It has no special protection against the intrusion of liquids or objects into the system. There is therefore a risk of lethal electric shock.

- Never touch the speaker with wet hands!
- Only use the speaker in a dry place!
- Do not operate it outdoors or in damp rooms!
- The loudspeaker must be protected from liquids of all kinds, including dripping and splashing water.
- Do not place any containers containing liquids (e.g. flower vases) on the speaker or in the immediate vicinity!
- If the loudspeaker is moved from a cold environment to a warm room, condensation may form inside the unit. Wait at least six hours until the loudspeaker has reached room temperature and is dry before switching it on!
- No objects of any kind may get into the device.
- Should the loudspeaker come into contact with liquids or should objects have gotten inside, please unplug the mains plug immediately and contact Nubert electronic GmbH (info@nubert.de)!

Danger of injury or damage!
Concerning speakers with threaded sockets on the underside of the housing: The threaded sockets on the underside of the housing may only be used to mount the supplied speaker feet!
They are not designed for tensile loads and must therefore not be used as a holder for hooks or similar to hang the speaker from. A falling speaker can cause serious injury and damage.

CONNECTION INSTRUCTIONS

Allgemeine Anschlusshinweise
Disconnect the mains plug before changing any wiring on the system!

- Make sure that all connections have been made correctly and that all plugs are firmly seated in the sockets before connecting the speaker to the mains.
- Use only the intended cables or plug connections for the connections! Failure to do so may result in damage or malfunction.
- If you want to disconnect connections on the loudspeaker, always pull the plug, never the cable!
- Ensure that all plugs are firmly seated in the sockets!
- Only use cables and accessories recommended by Nubert!

Disposal instructions

DISPOSAL OF ELECTRICAL AND ELECTRONIC DEVICES

Information according to the German Act on Electrical and Electronic Devices (ElektroG)

Owners of waste electrical and electronic devices must dispose of it separately from unsorted municipal waste.

Meaning of the symbol „crossed-out trash can“

The crossed-out garbage can symbol regularly displayed on electrical and electronic equipment and batteries indicates that the respective device must be collected separately from unsorted municipal waste.

Batteries, accumulators and lamps

Spent batteries and accumulators that are not enclosed by the waste equipment, as well as lamps that can be non-destructively removed from the waste equipment, have to be separated from the waste equipment before handing it in at a collection point.
If the waste equipment is to be prepared for reuse with the participation of a public waste management authority, batteries and accumulators as well as lamps do not have to be removed.

Deletion of data

Old devices may contain personal data. In your own interest, please note that you, as the end user, are responsible for deleting the personal data on the old devices to be disposed of before handing them in.

Options for the return of old devices

Owners of old devices from private households can hand them in free of charge at the local collection points of the public waste disposal authorities or at the collection points set up by manufacturers or distributors.

Distributors of electrical and electronic devices are obligated to take back old devices free of charge in accordance with § 17 Sections 1 and 2 of the Electrical and Electronic Equipment Act (ElektroG). The take-back process is as follows:
Distributors with a sales area of at least 400 m^2 for electrical and electronic equipment and distributors of groceries with a total sales area of at least 800 m^2 who offer electrical and electronic equipment several times per calendar year or on a permanent basis and make it available on the market are subject to the obligation to take the devices back. This applies in the case of distribution using means of distance selling (e.g. online retailers), with the stipulation that the relevant floorspace depends on the storage and shipping areas for electrical and electronic equipment.
Distributors subject to the take-back obligation must,

- when supplying a new electric or electronic device to an end-user, take back free of charge an end-user's old device of the same type that fulfills essentially the same functions as the new device at the place of supply or in the immediate vicinity thereof. If the device is delivered to a private household, the consumer may demand the collection of the old device at that location.
  In the case of distribution using means of distance selling (e.g. online store), free collection is limited to electrical and electronic equipment in categories 1, 2 and 4, namely "heat exchanger", "Screens, monitors and devices containing screens with a surface area greater than 100 square centimeters" or "large equipment" (the latter with at least one external dimension over 50 centimeters). For equipment in categories 3, 5 and 6, the distributor must ensure suitable return options within a reasonable distance from the respective end user.
- at the request of the end user, take back free of charge at the retail outlet, or in the immediate vicinity thereof, waste equipment that does not exceed 25 cm in any external dimension; take-back must not be linked to the purchase of an electrical or electronic device and is limited to three old devices per type of device.
  In the case of distribution using means of distance selling, the distributor must ensure appropriate return options at a reasonable distance from the respective end user.